



Strongwall Industries Technical Bulletin

CRACK TREATMENT DETAIL

1. Route and fill crack using High Point Load Sealant or equal as approved by specifier.
2. Apply one coat EM-100-N, set PPR fabric in uncured EM-100-N, allow to cure.
3. Apply (thickened) EM-100-N until fabric is completely covered, broadcast clean dry 10-20 mesh sand into final coat. (thickener to be supplied separately).
4. Allow final detail to cure (*approx. 2-3 hours*) before coating.

