



ROCKBOND RB-111

Care and Maintenance

Breathable High Build Finishing System

Routine care and maintenance includes many activities that can be completed by in-house personnel. Initiate a cleaning program in which the ROCKBOND High Build Vertical Finishing System is power washed when necessary.

For best results, use a mild cleaning solution of "Simple Green" or dish soap to maintain its appearance. Wash using either a bristle brush or a 1,000 psi light power-wash. Regular cleaning will prevent a build-up of residue. Pre-treat and "spot-clean" all oil, grease, dirt and organic matter by scrubbing with soft brushes while using an ammoniated detergent. Certain stains may require a diluted Clorox solution, degrease and hot power wash.

ROCKBOND RB-111 should be protected from equipment or objects causing damage such as gouging or scraping of the installation. Do not expose the ROCKBOND system to harsh chemicals or acids.

ROCKBOND RB-111 is typically coated with a topping to enhance UV resistance, color uniformity, cleanability, and wear. This Resicolor topping is designed to withstand direct exposure to the elements when installed as per the manufacturer's installation and environmental guidelines.

Never apply anything impermeable to the ROCKBOND RB-111 System as in order to function properly, ROCKBOND must be able to breathe and transmit moisture vapor from the substrate.

Should ROCKBOND RB-111 be damaged, it can be repaired by the owner or a Strongwall Certified Applicator. Please contact Strongwall Industries Inc. for further assistance at www.strongwall.com or by calling (201) 445-4633.