



## Application Guideline for Strongwarn SW-552 Primer

	Installation Step	Installation Methods	Products & Mix Ratios	Theoretical Coverage Rates
Step 1	<ul style="list-style-type: none"> <li>➤ Clean substrate of all dirt, grease, and other potential contaminants</li> </ul>	<ul style="list-style-type: none"> <li>➤ Light sanding</li> <li>➤ Vacuum</li> <li>➤ Solvent-wipe</li> <li>➤ Other similar and approved mechanical methods</li> </ul>	Strongwarn SW-552 Primer must be applied to a clean, sound substrate.	N/A
Step 2	Apply Strongwarn SW-552	<ul style="list-style-type: none"> <li>➤ Squeegee / backroll; or</li> <li>➤ Hudson Sprayer / backroll</li> </ul>	<p>Mix rate: Use as supplied</p>	<p>Covers: 300 ft<sup>2</sup> / gallon (5.34 wet film thickness) Minimum cure time: 4 hours</p>
Step 2a	<p>Optional, for porous substrate: Apply second coat of Strongwarn SW-552</p>	<ul style="list-style-type: none"> <li>➤ Squeegee / backroll; or</li> <li>➤ Hudson Sprayer / backroll</li> </ul>	<p>Mix rate: Use as supplied</p>	<p>Covers: 300 ft<sup>2</sup> / gallon (5.34 wet film thickness) Minimum cure time: 4 hours</p>

Note: Prior to starting the application of any SWI product or system, be sure to read the product data sheets, MSDS and other pertinent documents. Pay special attention to substrate moisture content, physical condition of the substrate, method(s) of surface preparation, surface restoration, detailing of cracks, joints, transitions and terminations, and any applicable specifications. Review carefully for unknown site conditions or defects.

**The theoretical coverage rates stated in this application specification are for estimating purposes only. Factors, such as, allowance for material waste, unusual or abnormal substrate conditions and other unforeseen job site conditions that may affect actual product yields are the responsibility of the installer.**